| | JEEP INJ Function List () | Note:For reference only) | |
|-------------------------------------|--------------------------------------|----------------------------------|--|
| NOTES: | | | |
| ullet This function is s | supported. | | |
| * This function may | be supported, which depends on the a | actual condition of the vehicle. | |
| O This function is n | ot supported. | | |
| \blacktriangle This function is t | he new feature in this version. | | |
| Vehicle | Year | INJ | |
| Cherokee | 2014-2015 | • | |
| Commander | 2006-2010 | • | |
| Compass | 2010-2017 | • | |
| Grand Cherokee | 2005-2017 | • | |
| Liberty | 2011-2013 | • | |
| Wrangler | 2008-2017 | • | |
| Wrangler(Export) | 2008-2017 | • | |

| JEEP OIL Function List (Note:For reference only | r) |
|---|----|
|---|----|

| JEEP | OIL Function Lis | st (Note:For reference only) | |
|--|-----------------------|---|--|
| NOTES: | | | |
| ullet This function is supported | | | |
| st This function may be suppo | rted, which depends o | on the actual condition of the vehicle. | |
| $\ensuremath{\bigcirc}$ This function is not suppo | rted. | | |
| lacksquare This function is the new f | eature in this versio | on. | |
| Vehicle | Year | OIL | |
| Charger | 2011-2017 | • | |
| Cherokee | 2014-2017 | • | |
| Compass | 2007-2017 | • | |
| Dart | 2014-2016 | • | |
| Durango(Post-2011) | 2014-2017 | • | |
| Journey | 2008-2017 | • | |
| Liberty | 2014-2015 | • | |
| Renegade | 2015-2017 | • | |
| Wrangler 2014-2017 • | | | |
| Wrangler(Export) | 2016-2017 | | |

| | JEEP SAS Functio | on List (Note:For reference only) |
|---------------------|-----------------------|---|
| NOTES: | - | · |
| • This function is | supported. | |
| ※ This function may | be supported, which | depends on the actual condition of the vehicle. |
| O This function is | not supported. | |
| ▲ This function is | the new feature in th | nis version. |
| Vehicle | Year | SAS |
| Charger | 2005-2017 | • |
| Cherokee | 2014-2017 | • |
| Commander | 2006-2010 | • |
| Compass | 2007-2017 | • |
| Grand Cherokee | 2005-2017 | • |
| Liberty | 2007-2015 | • |
| Renegade | 2015-2017 | • |

| | JEEP BLD Function Li | st (Note:For reference only) |
|----------------------------|-----------------------------------|--|
| NOTES: | | |
| ullet This function i | s supported. | |
| ∦ This function m | ay be supported, which depends on | n the actual condition of the vehicle. |
| O This function i | s not supported. | |
| lacksquare This function i | s the new feature in this version | l. |
| Vehicle | Year | BLD |
| Cherokee | 2014-2017 | • |
| Commander | 2006-2010 | • |
| Compass | 2007-2017 | • |
| Grand Cherokee | 2006-2017 | • |
| Liberty | 2011-2013 | • |
| Nitro | 2012-2017 | • |
| Wrangler | 2007-2015 | • |

JEEP Diagnostic Function List(Note:For reference only)

| ual condi | on of the vehicle. |
|-----------|--------------------|
| | |
| | |
| Year | Model |
| 2017 | Cherokee |
| 2017 | Compass - Brazil |
| 2017 | Compass - China |
| 2017 | Compass - Other |
| 2017 | Compass/Patriot |
| 2017 | Grand Cherokee |
| 2017 | Renegade |
| 2017 | Wrangler |
| 2017 | Wrangler (Export) |
| 2016 | Cherokee |
| 2016 | Compass/Patriot |
| 2016 | Grand Cherokee |
| 2016 | Renegade |
| 2016 | Wrangler |
| 2016 | Wrangler (Export) |
| 2015 | Cherokee |
| 2015 | Compass/Patriot |
| 2015 | Grand Cherokee |
| 2015 | Liberty |
| 2015 | Renegade |
| 2015 | Wrangler |
| 2015 | Wrangler (Export) |
| 2014 | Cherokee |
| 2014 | Compass/Patriot |
| 2014 | Grand Cherokee |
| 2014 | Liberty |
| 2014 | Wrangler |
| 2014 | Wrangler (Export) |
| 2013 | Compass/Patriot |
| 2013 | Grand Cherokee |
| 2013 | Liberty |
| 2013 | Wrangler |
| 2013 | Wrangler (Export) |
| 2012 | Compass/Patriot |
| 2012 | Grand Cherokee |
| 2012 | Liberty |
| 2012 | Wrangler |
| 2012 | Wrangler (Export) |
| 2011 | Compass/Patriot |
| 2011 | Grand Cherokee |
| 2011 | Liberty |
| 2011 | Wrangler |
| 2011 | Wrangler (Export) |
| 2010 | Commander |
| 2010 | Compass/Patriot |
| 2010 | Grand Cherokee |
| 2010 | Liberty |
| 2010 | Wrangler |
| | Liberty |

| | 0000 | 0 1 | | |
|--|---|---------------|---|---|
| JEEP | 2009 | Commander | | |
| JEEP | 2009 | Compass/Patri | | |
| JEEP | 2009 | Grand Cheroke | e | |
| JEEP | 2009 | Liberty | | |
| JEEP | 2009 | Wrangler | | |
| JEEP | 2009 | Wrangler (Exp | ort) | |
| JEEP | 2008 | Commander | | |
| JEEP | 2008 | Compass/Patri | | |
| JEEP | 2008 | Grand Cheroke | e | |
| JEEP | 2008 | Liberty | | |
| JEEP | 2008 | Wrangler | | |
| JEEP | 2008 | Wrangler (Exp | ort) | |
| JEEP | 2007 | Commander | | |
| JEEP | 2007 | Compass/Patri | | |
| JEEP | 2007 | Grand Cheroke | e | |
| JEEP | 2007 | Liberty | | |
| JEEP | 2007 | Wrangler | | |
| JEEP | 2006 | Commander | | |
| JEEP | 2006 | Compass/Patri | ot | |
| JEEP | 2006 | Grand Cheroke | e | |
| JEEP | 2006 | Liberty | | |
| JEEP | 2005 | Grand Cheroke | e | |
| JEEP | 2005 | Liberty | | |
| JEEP | 2005 | Wrangler | | |
| JEEP | 2004 | Grand Cheroke | e | |
| JEEP | 2004 | Liberty | | |
| JEEP | 2004 | Wrangler | | |
| JEEP | Before 2004 | Before 2004 | | |
| System | ECU INFO. | Read Code | Clear Code | View Data |
| PCM (Power Control Module) | • | • | • | • |
| PCM (Powertrain Control Module)(Type 1) | • | • | • | • |
| PCM (Powertrain Control Module)(Type 2) | • | • | • | • |
| RADIO | | - | | - |
| | • | • | • | • |
| TCM (Transmission Control Module)(Type 1) | • | • | • | • |
| | • | • | - | - |
| TCM (Transmission Control Module)(Type 1) | • • • | • | • | - |
| TCM (Transmission Control Module)(Type 1) TCM (Transmission Control Module)(Type 2) | • • • • | • | • | • |
| TCM (Transmission Control Module)(Type 1) TCM (Transmission Control Module)(Type 2) TCM (Transmission Control Module) | • • • • • | • | • | • |
| TCM (Transmission Control Module)(Type 1) TCM (Transmission Control Module)(Type 2) TCM (Transmission Control Module) ABS (Antilock Brake Controller) | • • • • • • | • | • | • • • • |
| TCM (Transmission Control Module)(Type 1) TCM (Transmission Control Module)(Type 2) TCM (Transmission Control Module) ABS (Antilock Brake Controller) ORC/SRS (Occupant Restraint Controller) | • • • • • • • • • | • | • • • • | • • • • • |
| TCM (Transmission Control Module)(Type 1) TCM (Transmission Control Module)(Type 2) TCM (Transmission Control Module) ABS (Antilock Brake Controller) ORC/SRS (Occupant Restraint Controller) BCM (Body Computer Module) | • • • • • • • • • • • • • • | | • • • • • • | |
| TCM (Transmission Control Module)(Type 1) TCM (Transmission Control Module)(Type 2) TCM (Transmission Control Module) ABS (Antilock Brake Controller) ORC/SRS (Occupant Restraint Controller) BCM (Body Computer Module) CCN/INSTR (Cabin Compartment Node/Instrument Cluster) | • • • • • • • • • • • • • • • • • • • | | | |
| TCM (Transmission Control Module)(Type 1) TCM (Transmission Control Module)(Type 2) TCM (Transmission Control Module) ABS (Antilock Brake Controller) ORC/SRS (Occupant Restraint Controller) BCM (Body Computer Module) CCN/INSTR (Cabin Compartment Node/Instrument Cluster) WCM (Wireless Control Module) | | | | • • • • • • • • • • • • • • • • • • • |
| TCM (Transmission Control Module)(Type 1) TCM (Transmission Control Module)(Type 2) TCM (Transmission Control Module) ABS (Antilock Brake Controller) ORC/SRS (Occupant Restraint Controller) BCM (Body Computer Module) CCN/INSTR (Cabin Compartment Node/Instrument Cluster) WCM (Wireless Control Module) HVAC (Heat Ventilation And A/C) | | | • • • • • • • • • • • • • • • • • • • | |
| TCM (Transmission Control Module)(Type 1) TCM (Transmission Control Module)(Type 2) TCM (Transmission Control Module) ABS (Antilock Brake Controller) ORC/SRS (Occupant Restraint Controller) BCM (Body Computer Module) CCN/INSTR (Cabin Compartment Node/Instrument Cluster) WCM (Wireless Control Module) HVAC (Heat Ventilation And A/C) OCM (Occupant Classification Module) | | | | |
| TCM (Transmission Control Module)(Type 1) TCM (Transmission Control Module)(Type 2) TCM (Transmission Control Module) ABS (Antilock Brake Controller) ORC/SRS (Occupant Restraint Controller) BCM (Body Computer Module) CCN/INSTR (Cabin Compartment Node/Instrument Cluster) WCM (Wireless Control Module) HVAC (Heat Ventilation And A/C) OCM (Occupant Classification Module) DDM (Drivers Door Module) | | | | |
| TCM (Transmission Control Module)(Type 1) TCM (Transmission Control Module)(Type 2) TCM (Transmission Control Module) ABS (Antilock Brake Controller) ORC/SRS (Occupant Restraint Controller) BCM (Body Computer Module) CCN/INSTR (Cabin Compartment Node/Instrument Cluster) WCM (Wireless Control Module) HVAC (Heat Ventilation And A/C) OCM (Occupant Classification Module) DDM (Drivers Door Module) PDM (Passengers Door Module) | | | • • | |
| TCM (Transmission Control Module)(Type 1) TCM (Transmission Control Module)(Type 2) TCM (Transmission Control Module) ABS (Antilock Brake Controller) ORC/SRS (Occupant Restraint Controller) BCM (Body Computer Module) CCN/INSTR (Cabin Compartment Node/Instrument Cluster) WCM (Wireless Control Module) HVAC (Heat Ventilation And A/C) OCM (Occupant Classification Module) DDM (Drivers Door Module) PDM (Passengers Door Module) PTS (Park Tronics) | | | • • | |
| TCM (Transmission Control Module)(Type 1) TCM (Transmission Control Module)(Type 2) TCM (Transmission Control Module) ABS (Antilock Brake Controller) ORC/SRS (Occupant Restraint Controller) BCM (Body Computer Module) CCN/INSTR (Cabin Compartment Node/Instrument Cluster) WCM (Wireless Control Module) HVAC (Heat Ventilation And A/C) OCM (Occupant Classification Module) DDM (Drivers Door Module) PDM (Passengers Door Module) PTS (Park Tronics) AMP (Amplifier) ACC (Adaptive Cruise Control) | | | | |
| TCM (Transmission Control Module)(Type 1) TCM (Transmission Control Module)(Type 2) TCM (Transmission Control Module) ABS (Antilock Brake Controller) ORC/SRS (Occupant Restraint Controller) BCM (Body Computer Module) CCN/INSTR (Cabin Compartment Node/Instrument Cluster) WCM (Wireless Control Module) HVAC (Heat Ventilation And A/C) OCM (Occupant Classification Module) DDM (Drivers Door Module) PDM (Passengers Door Module) PTS (Park Tronics) AMP (Amplifier) ACC (Adaptive Cruise Control) AHBM (Automatic High Beam Module) | | | | |
| TCM (Transmission Control Module)(Type 1) TCM (Transmission Control Module)(Type 2) TCM (Transmission Control Module) ABS (Antilock Brake Controller) ORC/SRS (Occupant Restraint Controller) BCM (Body Computer Module) CCN/INSTR (Cabin Compartment Node/Instrument Cluster) WCM (Wireless Control Module) HVAC (Heat Ventilation And A/C) OCM (Occupant Classification Module) DDM (Drivers Door Module) PDM (Passengers Door Module) PTS (Park Tronics) AMP (Amplifier) ACC (Adaptive Cruise Control) AHBM (Automatic High Beam Module) DMFR (Door Module Front Right) | | | | |
| TCM (Transmission Control Module)(Type 1) TCM (Transmission Control Module)(Type 2) TCM (Transmission Control Module) ABS (Antilock Brake Controller) ORC/SRS (Occupant Restraint Controller) BCM (Body Computer Module) CCN/INSTR (Cabin Compartment Node/Instrument Cluster) WCM (Wireless Control Module) HVAC (Heat Ventilation And A/C) OCM (Occupant Classification Module) DDM (Drivers Door Module) PDM (Passengers Door Module) PTS (Park Tronics) AMP (Amplifier) ACC (Adaptive Cruise Control) AHBM (Automatic High Beam Module) DMRR (Door Module Rear Right) | | | | |
| TCM (Transmission Control Module)(Type 1) TCM (Transmission Control Module)(Type 2) TCM (Transmission Control Module) ABS (Antilock Brake Controller) ORC/SRS (Occupant Restraint Controller) BCM (Body Computer Module) CCN/INSTR (Cabin Compartment Node/Instrument Cluster) WCM (Wireless Control Module) HVAC (Heat Ventilation And A/C) OCM (Occupant Classification Module) DDM (Drivers Door Module) PDM (Passengers Door Module) PTS (Park Tronics) AMP (Amplifier) ACC (Adaptive Cruise Control) AHBM (Automatic High Beam Module) DMFR (Door Module Front Right) DVD (DVD Player) | | | | |
| TCM (Transmission Control Module)(Type 1) TCM (Transmission Control Module)(Type 2) TCM (Transmission Control Module) ABS (Antilock Brake Controller) ORC/SRS (Occupant Restraint Controller) BCM (Body Computer Module) CCN/INSTR (Cabin Compartment Node/Instrument Cluster) WCM (Wireless Control Module) HVAC (Heat Ventilation And A/C) OCM (Occupant Classification Module) DDM (Drivers Door Module) PDM (Passengers Door Module) PTS (Park Tronics) AMP (Amplifier) ACC (Adaptive Cruise Control) AHBM (Automatic High Beam Module) DMFR (Door Module Front Right) DVD (DVD Player) ESM (Electronic Shifter Module) | | | | |
| TCM (Transmission Control Module)(Type 1) TCM (Transmission Control Module)(Type 2) TCM (Transmission Control Module) ABS (Antilock Brake Controller) ORC/SRS (Occupant Restraint Controller) BCM (Body Computer Module) CCN/INSTR (Cabin Compartment Node/Instrument Cluster) WCM (Wireless Control Module) HVAC (Heat Ventilation And A/C) OCM (Occupant Classification Module) DDM (Drivers Door Module) PDM (Passengers Door Module) PTS (Park Tronics) AMP (Amplifier) ACC (Adaptive Cruise Control) AHBM (Automatic High Beam Module) DMFR (Door Module Front Right) DMRR (Door Module Rear Right) DVD (DVD Player) ESM (Electronic Shifter Module) | | | | |
| TCM (Transmission Control Module)(Type 1) TCM (Transmission Control Module)(Type 2) TCM (Transmission Control Module) ABS (Antilock Brake Controller) ORC/SRS (Occupant Restraint Controller) BCM (Body Computer Module) CCN/INSTR (Cabin Compartment Node/Instrument Cluster) WCM (Wireless Control Module) HVAC (Heat Ventilation And A/C) OCM (Occupant Classification Module) DDM (Drivers Door Module) PDM (Passengers Door Module) PTS (Park Tronics) AMP (Amplifier) ACC (Adaptive Cruise Control) AHBM (Automatic High Beam Module) DMFR (Door Module Front Right) DVD (DVD Player) ESM (Electronic Shifter Module) FDCM (Final Drive Control Module) | | | | |
| TCM (Transmission Control Module)(Type 1) TCM (Transmission Control Module)(Type 2) TCM (Transmission Control Module) ABS (Antilock Brake Controller) ORC/SRS (Occupant Restraint Controller) BCM (Body Computer Module) CCN/INSTR (Cabin Compartment Node/Instrument Cluster) WCM (Wireless Control Module) HVAC (Heat Ventilation And A/C) OCM (Occupant Classification Module) DDM (Drivers Door Module) PDM (Passengers Door Module) PTS (Park Tronics) AMP (Amplifier) ACC (Adaptive Cruise Control) AHBM (Automatic High Beam Module) DMFR (Door Module Front Right) DVD (DVD Player) ESM (Electronic Shifter Module) EOM (Electronic Overhead Module) HFM (Hands Free Module) | | | | |
| TCM (Transmission Control Module)(Type 1) TCM (Transmission Control Module)(Type 2) TCM (Transmission Control Module) ABS (Antilock Brake Controller) ORC/SRS (Occupant Restraint Controller) BCM (Body Computer Module) CCN/INSTR (Cabin Compartment Node/Instrument Cluster) WCM (Wireless Control Module) HVAC (Heat Ventilation And A/C) OCM (Occupant Classification Module) DDM (Drivers Door Module) PDM (Passengers Door Module) PTS (Park Tronics) AMP (Amplifier) ACC (Adaptive Cruise Control) AHBM (Automatic High Beam Module) DMFR (Door Module Front Right) DMRR (Door Module Rear Right) DVD (DVD Player) ESM (Electronic Shifter Module) EOM (Electronic Overhead Module) | | | | |

| AWD (All Wheel Drive) | • | • | • | |
|--|---|---|---|---|
| DMFL (Left Forward Door Module) | | • | • | • |
| DMRL (Left Rear Door Module) | | | • | |
| FSM (Folding Seat Module) | | | • | • |
| HIDT (High Intensity Discharge Translator) | | • | • | • |
| HSM (Heated Seat Module) | | • | • | • |
| SAS (Steering Angle Sensor) | | • | • | • |
| ITM (Intrusion Module) | • | • | • | • |
| LRSM (Light Rain Sensor Module) | • | • | • | • |
| PLGM (Power Lift Gate Module) | | • | • | • |
| PSDML (Power Sliding Door Module (Left)) | | | • | |
| PSDMR (Power Sliding Door Module (Right)) | | | • | • |
| PTIM (Police/Taxi Interface Module) | | | | • |
| SDAR (Satellite Digital Radio) | • | • | • | • |
| SDARV (Satellite Video Receiver) | | | • | • |
| VES (Vehicle Entertainment System) | | • | • | • |
| TM (Trailer) | | • | • | • |
| MSMD (Memory Seat Module) | | • | • | • |
| SUNR (Sunroof Module) | | | | |
| SCM (Steering Column Module) | | • | • | • |
| VES3 (Last Row Srceem) | | • | • | • |
| TPMS (Tire Pressure Monitoring Systems) | | • | • | • |
| PTCM (Power Top Control Module) | | | • | • |
| PEM (Passive Entry Module) | | • | • | • |
| VES2 (Second Row Screen) | | • | • | • |
| SCCM (Steering Column Control Module) | | • | • | • |
| IPC (Instrument Panel Cluster) | | | • | • |
| RFH (Radio Frequency Hub) | | | • | • |
| EPS (Electric Power Steering) | • | | • | • |
| ICS (Integrated Center Stack) | • | • | • | • |
| BSM (Blind Spot Module) | • | • | • | • |
| TGW (Telematics Gateway) | • | • | • | • |
| VSIM (Vehicle System Interface Module) | • | • | • | • |
| ADCM (Active Damping Control Module) | • | • | • | • |
| AFLS (Adaptive Front Lighting System) | • | • | • | • |
| DTCM (Drive Train Control Module) | • | • | • | • |
| ASCM (Air Suspension Control Module) | • | • | • | • |
| CTM (Central Telematics Module) | • | • | • | • |
| CSWM (Comfort Seat And Wheel Module) | • | • | • | • |
| EDM (External Disc Module) | • | • | • | • |
| PAM (Park Assist Module) | • | • | • | • |
| LBSS (Left Blind Spot Sensor) | - | • | • | • |
| RBSS (Right Blind Spot Sensor) | • | • | • | • |
| DCU (Dosing Control Unit) | • | • | • | • |
| ELSD (Electronic Limited Slip Differential) | • | • | • | • |
| EPB (Electric Parking Brake) | • | • | • | • |
| EPPM (Electronic Pedestrian Protection Module) | • | • | • | • |
| ESL (Electronic Steering Lock) | • | • | • | • |
| FFCM (Forward Facing Camera Module) | • | • | • | • |
| VGT (Variable Geometry Turbo) | - | • | • | • |
| VTM (Vehicle Tracking Module) | • | • | • | • |
| PTU (Power Transfer Unit) | • | • | • | • |
| RDM (Rear Drive Module) | • | • | • | • |
| BPCM (Battery Pack Control Module) | • | • | • | • |
| BTM (Battery Thermal Module) | | | | • |
| DISP (Front Display) | | | | • |
| DRM (Data Recorder Module) | | | | • |
| EAC (Electric A/C Compressor) | | • | • | • |
| LAO (EICUITO A/O COMPTESSOI) | • | - | - | - |

| EBG (Electronic Booster Gauge) | • | • | • | • |
|--|---|---|---|---|
| HCP (Hybrid Control Processor) | • | • | • | • |
| HGM (Hybrid Gateway Module) | • | • | • | • |
| ITBM (Integrated Trailer Brake Module) | • | • | • | • |
| MCPA (Motor Control Processor A) | • | • | • | • |
| MCPB (Motor Control Processor B) | • | • | • | • |
| MSM (Memory Seat/Memory Heated Seat) | • | • | • | • |
| OBCM (On Board Charging Module) | • | • | • | • |
| PHGM (Plug In Hybrid Gateway Module) | • | • | • | • |
| ABSO (Anti Lock Brakes OBD) | • | • | • | • |
| AHCP (Auxiliary Hybrid Control Module) | • | • | • | • |
| AHM (Additional Heater Module) | • | • | • | • |
| ANC (Active Noise Cancelation) | • | • | • | • |
| APM (Adjustable Pedal Module) | • | • | • | • |
| CVPM (Central Vision Processing Module) | • | • | • | • |
| DSM (Display Screen Module) | • | • | • | • |
| DTV (Digital Television) | • | • | • | • |
| EAM (Emergency Assistance Module) | • | • | • | • |
| EBBM (Electronic Brake Booster Module) | • | • | • | • |
| EOMR (Electronic Overhead Module Rear) | • | • | • | • |
| ETM (Entertainment Telematic Module) | • | • | • | • |
| HALF (Haptical Lane Feedback) | • | • | • | • |
| HVACR (Rear Climate Control) | • | • | • | • |
| MSMP (Memory Seat Module-Passager) | • | • | • | • |
| RRM (Radio Receiver Module) | • | • | • | • |
| TTM (Trailer Tow Module) | • | • | • | • |
| VRM (Video Routing Module) | • | • | • | • |
| TBM (Telematic Box Module) | • | • | • | • |
| SRS (Supplemental Inflatable Restraint System) | • | • | • | • |
| HVAC/ATC | • | • | • | • |
| IPM/FCM (Intelligent Power Module) | • | • | • | • |
| MIC (Instrument Cluster) | • | • | • | • |
| MHS/APM (Memory Heated Seat/Adjustable Pedal Module) | • | • | • | • |
| DAA (Digital Audio Amplifier) | • | • | • | • |
| AT-XCM (Transfer Case Module) | • | • | • | • |
| NAV (NAVigation System) | • | • | • | • |
| RSM (Rain Sensor Module) | • | • | • | • |
| LSAB (Left Side Airbag) | • | • | • | • |
| RSAB (Right Side Airbag) | • | • | • | • |
| OHC (Overhead Console) | • | • | • | • |
| VTS (Vehicle Theft Security System) | • | • | • | • |
| SKM (SKIM-Skreem) | • | • | • | • |
| SAR (Satellite Audio Receiver) | • | • | • | • |
| | | | | |
| SLA (Shift Level Assembly Module) | • | • | • | • |

IFFP DPF Function List (Note:For reference -- 1 --)

| | JEEP DPF Function | List (Note:For reference only) |
|---------------------|-----------------------------|--|
| NOTES: | | · |
| • This function is | supported. | |
| ℜ This function may | be supported, which depend | ds on the actual condition of the vehicle. |
| O This function is | not supported. | |
| ▲ This function is | the new feature in this ver | csion. |
| Vehicle | Year | DPF |
| Cherokee | 2014-2015 | • |
| Commander | 2006-2010 | • |
| Compass | 2007-2014 | • |
| Compass | 2017 | • |
| Grand Cherokee | 2005-2015 | • |
| Liberty | 2008-2013 | • |
| Nitro | 2007-2010 | • |
| Renegade | 2015-2017 | • |

| JEEP EPB Function List (Note:For reference only) | | | | |
|---|---|---|--|--|
| NOTES: | | | | |
| • This function is supported. | | | | |
| X This function may be supported, which depends on the actual condition of the vehicle. | | | | |
| O This function is not supported. | | | | |
| igtharpoonup This function is the | ▲ This function is the new feature in this version. | | | |
| Vehicle Year EPB | | | | |
| Cherokee | 2014-2016 | • | | |
| Renegade | 2015-2017 | • | | |

| | JEEP ETC Functio | on List (Note:For reference only) |
|----------------------|-----------------------|---|
| NOTES: | ~ | · · |
| • This function is | supported. | |
| ※ This function may | be supported, which | depends on the actual condition of the vehicle. |
| O This function is a | not supported. | |
| ▲ This function is | the new feature in th | his version. |
| Vehicle | Year | ETC |
| Cherokee | 2014-2017 | • |
| Commander | 2006-2010 | • |
| Compass | 2007-2017 | • |
| GraDakota Cherokee | 2005-2017 | • |
| Liberty | 2006-2017 | • |
| Nitro | 2007-2012 | • |
| Wrangler | 2007-2017 | • |
| Renegade | 2015-2017 | • |